


Standard Jazz Bass®



Solder = location for ground (earth) connections.